GROUP 11C

ENGINE MECHANICAL <2.4L ENGINE>

CONTENTS

GENERAL INFORMATION	11C-2
ENGINE DIAGNOSIS	11C-2
SERVICE SPECIFICATIONS	11C-3
SEALANTS	11C-4
SPECIAL TOOLS	11C-5
ON-VEHICLE SERVICE	11C-8
DRIVE BELT TENSION CHECK	11C-8
AUTO-TENSIONER CHECK	11C-9
VALVE CLEARANCE CHECK AND	
ADJUSTMENT	11C-11
IGNITION TIMING CHECK	11C-11
CURB IDLE SPEED CHECK	11C-13
IDLE MIXTURE CHECK	11C-14
COMPRESSION PRESSURE CHECK	11C-16
MANIFOLD VACUUM CHECK	11C-17
CRANKSHAFT PULLEY	11C-19
REMOVAL AND INSTALLATION	11C-19
CAMSHAFT	11C-24
REMOVAL AND INSTALLATION	11C-24

VALVE STEM SEAL	11C-38
REMOVAL AND INSTALLATION	11C-38
OIL PAN	11C-46
REMOVAL AND INSTALLATION	11C-46
INSPECTION	11C-48
CRANKSHAFT OIL SEAL	11C-49
REMOVAL AND INSTALLATION	11C-49
CYLINDER HEAD GASKET	11C-52
REMOVAL AND INSTALLATION	11C-52
TIMING CHAIN	11C-64
TIMING CHAIN Comparison Compa	11C-64 11C-64
TIMING CHAIN REMOVAL AND INSTALLATION BALANCER TIMING CHAIN, BALANC	11C-64 11C-64 ER
TIMING CHAIN REMOVAL AND INSTALLATION BALANCER TIMING CHAIN, BALANC SHAFT AND OIL PUMP MODULE	11C-64 11C-64 ER 11C-72
TIMING CHAIN REMOVAL AND INSTALLATION BALANCER TIMING CHAIN, BALANC SHAFT AND OIL PUMP MODULE REMOVAL AND INSTALLATION	11C-64 11C-64 ER 11C-72 11C-72
TIMING CHAIN REMOVAL AND INSTALLATION BALANCER TIMING CHAIN, BALANC SHAFT AND OIL PUMP MODULE REMOVAL AND INSTALLATION BALANCER SHAFT AND OIL PUMP	11C-64 11C-64 ER 11C-72 11C-72
TIMING CHAIN REMOVAL AND INSTALLATION BALANCER TIMING CHAIN, BALANC SHAFT AND OIL PUMP MODULE REMOVAL AND INSTALLATION BALANCER SHAFT AND OIL PUMP MODULE	11C-64 11C-64 ER 11C-72 11C-72 11C-76
TIMING CHAIN REMOVAL AND INSTALLATION BALANCER TIMING CHAIN, BALANC SHAFT AND OIL PUMP MODULE REMOVAL AND INSTALLATION BALANCER SHAFT AND OIL PUMP MODULE. REMOVAL AND INSTALLATION	11C-64 11C-64 ER 11C-72 11C-72 11C-76 11C-76
TIMING CHAIN	11C-64 11C-64 ER 11C-72 11C-72 11C-76 11C-76 11C-81

GENERAL INFORMATION

The 4B12 (2.4 L) engine is an in-line four-cylinder engine. The cylinder numbers are assigned as 1-2-3-4 from the front of the engine (timing chain side). The firing order is 1-3-4-2.

ITEMS			SPECIFICATIONS
Туре			In-line DOHC
Number of cylind	lers		4
Bore mm (in)			88 (3.5)
Stroke mm (in)			97 (3.8)
Total displaceme	ent cm ³ (cu. in)		2,360 (144.0)
Compression rat	io		10.5
Firing order			1-3-4-2
Valve timing	Intake valve	Opens (BTDC)	40° -0°
		Closes (ABDC)	64° –24°
	Exhaust valve	Opens (BBDC)	24° -44°
		Closes (ATDC)	0° –20°

ENGINE DIAGNOSIS

M1111000700433

SYMPTOMS	PROBABLE CAUSE	REMEDY
Compression is too	Blown cylinder head gasket	Replace the gasket.
low	Worn or damaged piston rings	Replace the rings.
	Worn piston or cylinder	Repair or replace the piston and/or the cylinder block.
	Worn or damaged valve seat	Repair or replace the valve and/or the seat ring
Drop in engine oil	Engine oil level is too low	Check the engine oil level.
pressure	Malfunction of engine oil pressure switch	Replace the engine oil pressure switch.
	Clogged oil filter	Install a new filter.
	Worn oil pump gears or cover	Replace the gears and/or the cover.
	Thin or diluted engine oil	Change the engine oil to the correct viscosity.
	Stuck (opened) oil relief valve	Repair the relief valve.
	Excessive bearing clearance	Replace the bearings.
Engine oil pressure too high	Stuck (closed) oil relief valve	Repair the relief valve.
Noisy valves	Incorrect valve clearance	Adjust valve clearance
	Thin or diluted engine oil (low engine oil pressure)	Change the engine oil.
	Worn or damaged valve stem or valve guide	Replace the valve and/or the guide.

TSB Revision

M1111000101605

ENGINE MECHANICAL <2.4L ENGINE> SERVICE SPECIFICATIONS

SYMPTOMS	PROBABLE CAUSE	REMEDY
Connecting rod	Insufficient oil supply	Check the engine oil level.
noise/main bearing noise	Thin or diluted engine oil	Change the engine oil.
	Excessive bearing clearance	Replace the bearings.

SERVICE SPECIFICATIONS

M1111000301836

Item		Standard value	Limit
Drive belt tension	Vibration frequency Hz (Reference)	102 –129	-
	Tension N (lb) (Reference)	248 –400 (56 – 90)	-
Valve clearance (at cold) mm (in)	Intake valve	0.20 ±0.03 (0.008 ±0.001)	-
	Exhaust valve	0.30 ±0.03 (0.012 ±0.001)	-
Basic ignition timing at idle		5° BTDC ± 3°	-
Actual ignition timing at curb idle		Approximately 10° BTDC	-
CO contents %		0.5 or less	-
HC contents ppm		100 or less	_
Curb idle speed r/min		650 ± 100	-
Compression pressure (200 r/min) kPa (psi)		1,440 (208.8)	Minimum 1,000 (145.0)
Compression pressure difference of all cylinder kPa (psi)		-	100 (14.5)
Intake manifold vacuum at curb idle kPa	(in Hg)	_	Minimum 60 (17.8)

SEALANTS

M1111000500763

Item	Specified sealant
Rocker cover assembly (matching area of the cylinder head and the timing chain case assembly)	Three bond 1217G (Mitsubishi Genuine Part No.1000A923), Three bond 1227D, LOCTITE 5900 or equivalent
Engine oil pan	Three bond 1217G (Mitsubishi Genuine Part No.1000A923), Three bond 1227D, Three bond 1207F (Mitsubishi Genuine Part No.1000A992), LOCTITE 5971, LOCTITE 5970, LOCTITE 5900 or equivalent
Flywheel bolt <m t=""> or drive plate bolt <cvt></cvt></m>	Three bond 1324 or exact equivalent
Cylinder head gasket (matching area of the cylinder block and the cylinder head) Timing chain case assembly	Three bond 1217G (Mitsubishi Genuine Part No.1000A923), LOCTITE 5900 or equivalent
Timing chain case assembly	

SPECIAL TOOLS

M1111000602272

Тооі	Tool number and name	Supersession	Application
a b B992080	MB992080 Belt tension meter set a: MB9912081 Belt tension meter b: MB992082 Mic assembly	Tool not available	Drive belt tension (frequency) measurement
a MB991824 b MB991827 C MB991827 C MB991910 d DO NOT USE MB91911 f MB991914 f MB991914 f MB991825 g MB991825 g MB991825 g MB991825 g MB991825 g MB991825 g	MB991958 Scan tool (M.U.TIII sub assembly) a: MB991824 Vehicle communication interface (V.C.I.) b: MB991827 M.U.TIII USB cable c: MB991910 M.U.TIII main harness A (Vehicles with CAN communication system) d: MB991911 M.U.TIII main harness B (Vehicles without CAN communication system) e: MB991914 M.U.TIII main harness C (for Chrysler models only) f: MB991825 M.U.TIII adapter harness g: MB991826 M.U.TIII trigger harness	MB991824-KIT NOTE: MB991826 M.U.TIII Trigger Harness is not necessary when pushing V.C.I. ENTER key.	CAUTION For vehicles with CAN communication, use M.U.TIII main harness A to send simulated vehicle speed. If you connect M.U.TIII main harness B instead, the CAN communication does not function correctly. Ignition timing check Curb idle speed check Idle mixture check Erasing the diagnostic trouble code

11C-6

ENGINE MECHANICAL <2.4L ENGINE> SPECIAL TOOLS

Тооі	Tool number and name	Supersession	Application
MB992278	MB992278 Belt tension release wrench		Auto-tensioner tension release
© B990767	MB990767 Front hub and flange yoke holder	MB990767-01	Holding the crankshaft pulley
рания Сради D998719	MD998719 Pin	MIT308239	
B992103	MB992103 Chain tension release bar	_	Camshaft and camshaft sprocket assembly (exhaust side) removal
MD998772	MD998772 Valve spring compressor	General service tool	Valve spring compression
Б992090	MB992090 Retainer holder attachment	-	
	MB992089 Retainer holder C	-	
	MB992085 Valve stem seal pliers	_	Valve stem seal removal

ENGINE MECHANICAL <2.4L ENGINE> SPECIAL TOOLS

Tool	Tool number and name	Supersession	Application
	MD998737 Valve stem seal installer	MD998737-01	Valve stem seal press-fitting
D998727	MD998727 Oil pan FIPG cutter	MD998727-01	Engine oil pan removal
MB991883	MB991883 Flywheel stopper	General service tool	Supporting the flywheel <m t=""> or drive plate <cvt></cvt></m>
	MD998718 Crankshaft rear oil seal installer	MD998718-01	Press-fitting the crankshaft rear oil seal
	MB991448 Bush remover and installer base	MB991448-01	Press-fitting the crankshaft front oil seal
MB991614	MB991614 Angle gauge	-	Balancer shaft and oil pump module installation

11C-8

ENGINE MECHANICAL <2.4L ENGINE> ON-VEHICLE SERVICE

Tool	Tool number and name	Supersession	Application
		Supersession	Application
B991454	MB991454 Engine hanger balancer	MZ203827-01	 Supporting the engine and transaxle assembly during removal and installation of the timing chain Supporting the engine
MB991895	MB991895 Engine hanger	Tool not available	assembly during removal and installation of the transaxle assembly NOTE: Special tool MB991454 is a part of
Slide bracket (HI)	MB991928 Engine hanger a: MB991929 Joint (50) × 2 b: MB991930 Joint (90) × 2 c: MB991931 Joint (140) × 2 d: MB991932 Foot (standard) × 4 e: MB991933 Foot (short) × 2 f: MB991934 Chain and hook assembly	Tool not available	engine hanger attachment set MB991453.
B992201	MB992201 Engine hanger plate	_	Transaxle assembly removal

ON-VEHICLE SERVICE

DRIVE BELT TENSION CHECK

M1111003102997

- 1. Remove the radiator condenser tank mounting bolts.
- 2. Move the radiator condenser tank to a place where it will not be a hindrance when checking the drive belt tension.

۱
۱





Check the drive belt tension after turning the crankshaft clockwise one turn or more.

- 3. Make sure that the indicator mark on the auto-tensioner is within the area marked with A in the illustration.
- 4. If the mark is out of the area A, replace the drive belt (Refer to P.11C-19.)

NOTE: The drive belt tension check is not necessary as the auto-tensioner is adopted.

5. Tighten the radiator condenser tank mounting bolts to the specified torque.

Tightening torque: 12 \pm 2 N \cdot m (102 \pm 22 in-lb)

AUTO-TENSIONER CHECK

M1111003001942

Required Special Tool:

OPERATION CHECK

MB992278: Belt tension release wrench

- 1. Turn off the engine from the idle state then check to see that the drive belt is not protruding from the pulley width of the auto-tensioner.
- 2. Remove the drive belt (Refer to P.11C-19.)
- 3. Using the special tool MB992278 and a straight offset wrench as shown, check that no binding is present by turning the auto-tensioner in the left and right directions.
- 4. If there are any problems in the procedure 1 or 3, replace the auto-tensioner (Refer to P.11C-64.)
- 5. Install the drive belt (Refer to P.11C-19.)

FUNCTION CHECK

The auto-tensioner can be checked whether it is in good condition by checking its tension.

<When the vibration frequency is measured: Recommendation>

Required Special Tools:

- MB992080: Belt Tension Meter Set
 - MB992081: Belt Tension Meter
 - MB992082: Mic Assembly
- 1. Check the tension of the drive belt (Refer to P.11C-8.)
- 2. Check the tension of the drive belt in the following procedures.

TSB Revision

ENGINE MECHANICAL <2.4L ENGINE> ON-VEHICLE SERVICE





- Connect special tool MB992082 to special tool MB992081 of special tool MB992080.
- (2) Press the "POWER" button to turn on the power supply.
- (3) Press the numeral key of "1" and check that "No. 1" appears on the upper left of the display.

NOTE: This operation is to temporarily set the preset data such as the belt specifications, because if the measurement is taken without input of the belt specifications, conversion to tension value (N) cannot be made, resulting in judgement of error.

(4) Press "Hz" button twice to change the display to the frequency display (Hz.)

- The temperature of the surface of the belt should be as close to normal temperature as possible.
- Do not allow any contaminants such as water or oil to get onto the microphone.
- If strong gusts of wind blow against the microphone or if there are any loud sources of noise nearby, the values measured by the microphone may not correspond to actual values.
- If the microphone is touching the belt while the measurement is being made, the values measured by the microphone may not correspond to actual values.
- Do not take the measurement while the vehicle's engine is running.
- (5) Hold special tool MB992080 to the middle of the belt between the pulleys (at the place indicated by arrow) where it does not contact the belt [approximately 10 –15 mm (0.4 –0.59 inch) away from the rear surface of the belt] so that it is perpendicular to the belt (within an angle of \pm 15 degree angle.)
- (6) Press the "MEASURE" button.
- (7) Gently tap the middle of the belt between the pulleys (the place indicated by the arrow) with your finger as shown in the illustration, and check that the vibration frequency of the belt is within the standard value.

Standard value: 102 –129 Hz

NOTE: To take the measurement repeatedly, tap the belt again.

- (8) Press and hold the "POWER" button to turn off the power supply.
- 3. If not within the standard value, replace the auto-tensioner (Refer to P.11C-64.)

TSB Revision	
--------------	--



<When using a tension gauge>

- 1. Check the tension of the drive belt (Refer to P.11C-8.)
- 2. Use a belt tension gauge in the middle of the belt between the pulleys shown in the figure (at the place indicated by the arrow) to check that the belt tension is within the standard value.

Standard value: 248 -400 N (56 -90 lb)

3. If not within the standard value, replace the auto-tensioner (Refer to P.11C-64.)

VALVE CLEARANCE CHECK AND ADJUSTMENT

Refer to GROUP00, Maintenance service <2.4L ENGINE> – Intake And Exhaust Valve Clearance (Inspect And Adjust) P.00-85.

IGNITION TIMING CHECK

M1111001702755

Required Special Tool:

MB991958: Scan Tool (M.U.T.-III Sub Assembly)

- MB991824: V.C.I.
 - MB991827: M.U.T.-III USB Cable
 - MB991910: M.U.T.-III Main Harness A

1. Before inspection, set the vehicle in the following condition:

- Engine coolant temperature: 80 –95° C (176 –203° F)
- · Lights and all accessories: OFF
- Transaxle: Neutral (P range on vehicles with CVT)

NOTE: On vehicles for Canada, the headlight, taillight, etc. remain lit even when the lighting switch is in "OFF" position but this is no problem for checks.





To prevent damage to scan tool MB991958, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991958.

2. Connect scan tool MB991958 to the data link connector.

- 3. Set the timing light to the terminal No. 3 power supply line (white-red) of the ignition coil No. 1.
- 4. Start the engine and run it at idle.
- 5. Check that the idle speed is approximately 650 r/min.
- 6. Select scan tool MB991958 actuator test "item number 11".
- 7. Check that basic ignition timing is within the standard value. Standard value: 5° BTDC $\pm 3^{\circ}$
- If the basic ignition timing is not within the standard value (Refer to GROUP 13B, Multiport Fuel Injection (MFI) Diagnosis –Symptom Chart P.13B-56).

If the actuator test is not canceled, the forced drive will continue for 27 minutes. Driving in this state could lead to engine failure.

- 9. Cancel the setting mode of the scan tool MB991958.
- 10.Check that the actual ignition timing is at the standard value.

Standard value: Approximately 10° BTDC

NOTE: The ignition timing fluctuates about $\pm 7^{\circ}$, even under normal operating condition.

NOTE: It is automatically further advanced by about 5° from 10° Before Top Dead Center at higher altitudes.

NOTE: Wait till approximately 1 minute passes after the engine started, and check the ignition timing when the engine stabilized.

11.Remove the timing light.

TSB Revision

To prevent damage to scan tool MB991958, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991958.

12.Disconnect scan tool MB991958 from the data link connector.

CURB IDLE SPEED CHECK

M1111003502757

Required Special Tool:

MB991958: Scan Tool (M.U.T.-III Sub Assembly)

- MB991824: V.C.I.
- MB991827: M.U.T.-III USB Cable
- MB991910: M.U.T.-III Main Harness A
- 1. Before inspection, set the vehicle in the following condition:
- Engine coolant temperature: 80 –95° C (176 –203° F)
- · Lights and all accessories: OFF
- Transaxle: Neutral (P range on vehicles with CVT) NOTE: On vehicles for Canada, the headlight, taillight, etc.

remain lit even when the lighting switch is in "OFF" position but this is no problem for checks.

To prevent damage to scan tool MB991958, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991958.

2. Connect scan tool MB991958 to the data link connector.



TSB Revision

ENGINE MECHANICAL <2.4L ENGINE> ON-VEHICLE SERVICE



- 3. Set the timing light to the terminal No. 3 power supply line (white-red) of the ignition coil No. 1.
- 4. Start the engine.
- 5. Run the engine at idle for 2 minutes.
- 6. Check the actual ignition timing is at the standard value.

Standard value: Approximately 10° BTDC

NOTE: The ignition timing fluctuates about $\pm 7^{\circ}$, even under normal operating condition.

NOTE: It is automatically further advanced by about 5° from 10° Before Top Dead Center at higher altitudes.

NOTE: Wait till approximately 1 minute passes after the engine started, and check the ignition timing when the engine stabilized.

7. Check the idle speed. Select item number 2 and take a reading of the idle speed.

Curb idle speed: 650 \pm 100 r/min

NOTE: The idle speed is controlled automatically by the idle air control system.

- If the idle speed is outside the standard value (Refer to GROUP 13B, Multiport Fuel Injection (MFI) Diagnosis – Symptom Chart P.13B-56).
- 9. Remove the timing light.

To prevent damage to scan tool MB991958, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991958.

10.Disconnect scan tool MB991958 from the data link connector.

IDLE MIXTURE CHECK

M1111002102013

Required Special Tool:

MB991958: Scan Tool (M.U.T.-III Sub Assembly)

- MB991824: V.C.I.
- MB991827: M.U.T.-III USB Cable
- MB991910: M.U.T.-III Main Harness A
- 1. Before inspection, set the vehicle in the following condition:
- Engine coolant temperature: 80 –95° C (176 –203° F)
- · Lights and all accessories: OFF
- Transaxle: Neutral (P range on vehicles with CVT)

NOTE: On vehicles for Canada, the headlight, taillight, etc. remain lit even when the lighting switch is in "OFF" position but this is no problem for checks.



No. 1 ignition coil

Equipment side connector

Power supply line (terminal No. 3)

3

AK604618 AB

To prevent damage to scan tool MB991958, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991958.

2. Connect scan tool MB991958 to the data link connector.

- 3. Set the timing light to the terminal No. 3 power supply line (white-red) of the ignition coil No. 1.
- 4. Start the engine and let it run at idle.
- 5. Check that the actual ignition timing is at the standard value. **Standard value: Approximately 10° BTDC**

NOTE: The ignition timing fluctuates about $\pm 7^{\circ}$, even under normal operating condition.

NOTE: It is automatically further advanced by about 5° from 10° Before Top Dead Center at higher altitudes.

NOTE: Wait till approximately 1 minute passes after the engine started, and check the ignition timing when the engine stabilized.

- 6. Run the engine and increase the engine speed to 2,000 3,000 r/min for 2 minutes.
- 7. Set the CO, HC tester.
- 8. Check the CO contents and the HC contents at idle.

Standard value: CO contents: 0.5% or less HC contents: 100 ppm or less

 If there is a deviation from the standard value, inspect the MFI system (Refer to GROUP 13B, Multiport Fuel Injection (MFI) Diagnosis –Symptom Chart P.13B-56).

10. Remove the CO, HC tester and timing light.

To prevent damage to scan tool MB991958, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991958.

11.Disconnect scan tool MB991958 from the data link connector.

COMPRESSION PRESSURE CHECK

Required Special Tool:

MB991958: Scan Tool (M.U.T.-III Sub Assembly)

- MB991824: V.C.I.
- MB991827: M.U.T.-III USB Cable
- MB991910: M.U.T.-III Main Harness A
- 1. Before inspection, check that the engine oil, starter and battery are normal. Also, set the vehicle in the following condition:
- Engine coolant temperature: 80 –95° C (176 –203° F)
- · Lights and all accessories: OFF
- Transaxle: Neutral (P range on vehicles with CVT) NOTE: On vehicles for Canada, the headlight, taillight, etc. remain lit even when the lighting switch is in "OFF" position but this is no problem for checks.
- 2. Turn the ignition switch to the "LOCK" (OFF) position.
- 3. Disconnect the connector of the ignition coil, and then remove all the ignition coils and the spark plugs.
- 4. Disconnect the all of the injector connectors.

A WARNING

Keep your distance from the spark plug hole when cranking. Oil, fuel, etc., may spray out from the spark plug hole and may cause serious injury.

- 5. Cover the spark plug hole with a shop towel etc., after the engine has been cranked, check that no foreign material is adhering to the shop towel.
- 6. Set compression gauge to one of the spark plug holes.
- 7. Crank the engine with the throttle valve fully open and measure the compression pressure.

Standard value (at engine speed of 200 r/min): 1,440 kPa (208.8 psi)

Limit (at engine speed of 200 r/min): Minimum 1,000 kPa (145.0 psi)

8. Measure the compression pressure for all the cylinders, and check that the pressure differences of the cylinders are below the limit.

Limit: Maximum 100 kPa (14.5 psi)

- 9. If there is a cylinder with compression or a compression difference that is outside the limit, pour a small amount of engine oil through the spark plug hole, and repeat the operations in steps from 6 to 8.
 - (1) If the compression increases after oil is added, the cause of the malfunction is a worn or damaged piston ring and/or cylinder inner surface.
 - (2) If the compression does not rise after oil is added, the cause is a burnt or defective valve seat, or pressure is leaking from the gasket.

10.Connect the all of the injector connector.

TSB Revision	







- 11.Install the spark plugs and ignition coils.
- 12.Use the scan tool MB991958 to erase the diagnosis codes. NOTE: This will erase the diagnosis code resulting from the
- injector connectors being disconnected.
 13.Select "Mode \$0A" from "Special Function" of Scan tool MB991958. Check whether the permanent-DTC (PDTC) is stored or not. If stored, clear the PDTC. (Refer to GROUP 13B –Multiport Fuel Injection (MFI) <2.4 L Engine> – Multiport Fuel Injection (MFI) Diagnosis –Diagnostic Function P.13B-12)

MANIFOLD VACUUM CHECK

M1111002702167

Required Special Tool:

MB991958: Scan Tool (M.U.T.-III Sub Assembly)

- MB991824: V.C.I.
- MB991827: M.U.T.-III USB Cable
- MB991910: M.U.T.-III Main Harness A
- 1. Before inspection, set the vehicle in the following condition:
- Engine coolant temperature: 80 –95° C (176 –203° F)
- · Lights and all accessories: OFF
- Transaxle: Neutral (P range on vehicles with CVT)

NOTE: On vehicles for Canada, the headlight, taillight, etc. remain lit even when the lighting switch is in "OFF" position but this is no problem for checks.



Vacuum gauge

0 1 0 0

PCV valve

AK502601AE

Plug

To prevent damage to scan tool MB991958, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991958.

2. Connect scan tool MB991958 to the data link connector.

- 3. Disconnect the ventilation hose from the positive crankcase ventilation (PCV) valve, and then connect a vacuum gauge to the ventilation hose. Plug the PCV valve.
- 4. Start the engine and check that idle speed is approximately 650 r/min.
- 5. Check the intake manifold vacuum.

Limit: Minimum 60 kPa (17.8 in Hg)

- 6. Turn off the ignition switch.
- 7. Remove the vacuum gauge and then connect the ventilation hose to the PCV valve.

To prevent damage to scan tool MB991958, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991958.

8. Disconnect scan tool MB991958 from the data link connector.

TSB Revisior	۱
---------------------	---

11C-19

CRANKSHAFT PULLEY

REMOVAL AND INSTALLATION

M1112001602955

Pre-removal Operation

 Engine Room Under Cover Front B and Engine Room Side Cover (RH) Removal (Refer to GROUP 51, Under Cover P.51-20.)

Post-installation Operation

- Drive Belt Tension Check (Refer to P.11C-8.)
- Engine Room Under Cover Front B and Engine Room Side Cover (RH) Installation (Refer to GROUP 51, Under Cover P.51-20.)



Removal steps

- 1. Radiator condenser tank assembly
- <<**B**>> >>**B**<< 2. Drive belt
- <<C>>> >> A<< 3. Crankshaft pulley center bolt

Required Special Tools:

- MB992278: Belt Tension Release Wrench
- MB990767: Front Hub and Flange Yoke Holder
- MD998719: Pin

<<**A**>>

۲ <<**C**>> >>**A**<< 4. (

<<C>>

Removal steps (Continued)

- . Crankshaft pulley washer
- >>A<< 5. Crankshaft pulley

REMOVAL SERVICE POINTS

<<A>> RADIATOR CONDENSER TANK ASSEM-BLY REMOVAL

Remove the radiator condenser tank assembly mounting bolt, and move the radiator condenser tank assembly to a place where it does not interfere with the drive belt removal and installation.

<> DRIVE BELT REMOVAL

Since the serpentine drive system with the auto-tensioner is used, the following operations will be required.

To reuse the drive belt, draw an arrow indicating the rotating direction on the back of the belt using chalk to install the same direction.

- 1. Rotate the pulley bolt of the auto-tensioner counterclockwise with an special tool MB992278 and insert the L-shaped hexagon wrench into the auto-tensioner hole to fix the auto-tensioner.
- 2. Remove the drive belt.



MB992278



<<C>> CRANKSHAFT PULLEY CENTER BOLT/CRANKSHAFT PULLEY WASHER/CRANKSHAFT PULLEY REMOVAL

- 1. Hold the crankshaft pulley with special tools MB990767 and MD998719.
- 2. Loosen the crankshaft pulley center bolt and remove the crankshaft pulley center bolt, crankshaft pulley washer and crankshaft pulley.



•: Wipe clean with a rag.

INSTALLATION SERVICE POINTS

>>A<< CRANKSHAFT PULLEY/CRANKSHAFT PULLEY WASHER/CRANKSHAFT PULLEY CEN-TER BOLT INSTALLATION

- 1. Wipe off the dirt on the crankshaft and crankshaft pulley as shown in the figure using a rag.
- 2. Wipe off the dirt on the crankshaft sprocket, crankshaft and crankshaft pulley as shown in the figure using a rag, and then degrease them.

NOTE: Degrease them to prevent drop in the friction coefficient of the pressed area, which is caused by oil adhesion.

- 3. Install the crankshaft pulley.
- 4. Wipe off the dirt on the crankshaft pulley washer and crankshaft pulley center bolt as shown in the figure using a rag.
- 5. Apply an adequate and minimum amount of engine oil to the threads of the crankshaft pulley center bolt and lower area of the flange.

- 6. Hold the crankshaft pulley with special tools MB990767 and MD998719 in the same manner as removal.
- 7. Tighten the crankshaft pulley center bolt to the specified torque.

Tightening torque: 210 N· m (155 ft-lb)



TSB	Revision

ENGINE MECHANICAL <2.4L ENGINE> CRANKSHAFT PULLEY



>>B<< DRIVE BELT INSTALLATION

- To reuse the drive belt, install it by aligning the arrow mark on the backside of belt marked at the removal with the rotating direction.
- Check that the notches of the notched pulley and the notches of the drive belt are fit correctly.
- Check that the drive belt is installed in the center of the flat surface of the flat pulley.

1. Install the drive belt to each pulleys as shown in the figure.

ENGINE MECHANICAL <2.4L ENGINE> CRANKSHAFT PULLEY



- 2. Set an special tool MB992278 to the pulley bolt of the auto-tensioner. Then, rotate the auto-tensioner counterclockwise and remove the L-shaped hexagon wrench fixing the auto-tensioner.
- 3. Apply tension to the drive belt while slowly turning the auto-tensioner clockwise.

٠

CAMSHAFT

REMOVAL AND INSTALLATION

• Engine Room Under Cover Front A, B and Engine Room

· Air Cleaner Assembly Removal (Refer to GROUP 15, Air

Strut Tower Bar Removal (Refer to GROUP 42A, Strut

Ignition Coil Removal (Refer to GROUP 16, Ignition Sys-

Side Cover (RH) Removal (Refer to GROUP 51, Under

M1112007800906

Pre-removal Operation

Cover P.51-20.)

Cleaner P.15-10.)

Tower Bar P.42A-15.)

Post-installation Operation

- Ignition Coil Installation (Refer to GROUP 16, Ignition System –Ignition Coil P.16-51.)
- Strut Tower Bar Installation (Refer to GROUP 42A, Strut Tower Bar P.42A-15.)
- Air Cleaner Assembly Installation (Refer to GROUP 15, Air Cleaner P.15-10.)
- Engine Room Under Cover Front A, B and Engine Room Side Cover (RH) Installation (Refer to GROUP 51, Under Cover P.51-20.)



			Camshaft removal steps				Camshaft removal steps
		1.	Engine upper cover	< <f>></f>	>>E<<	15.	Camshaft and camshaft sprocket
		2.	Breather hose connection				assembly (exhaust side)
		3.	PCV hose connection	< <g>></g>	>> B <<	16.	Camshaft sprocket (exhaust side)
		4.	Control wiring harness	< <g>></g>	>> B <<	17.	Camshaft (exhaust side)
			connection		>>E<<	18.	Camshaft bearing
<< A >>	>>G<<	5.	Rocker cover assembly	< <e>>></e>	>>D<<	19.	Oil feed camshaft bearing cap
		6.	Rocker cover gasket				(intake side)
< >		•	Number 1 cylinder compression	< <e>></e>	>>D<<	20.	Camshaft bearing cap (intake
			top dead center setting (only at				side)
			removal.)	< <e>></e>	>>D<<	21.	Camshaft bearing cap (intake
		•	Valve clearance adjustment				side)
			(Refer to P.11C-11) (only at	< <e>></e>	>>D<<	22.	Thrust camshaft bearing cap
			installation.)		_		(intake side)
		7.	Timing chain upper guide		>>C<<	23.	Camshaft and camshaft sprocket
		8.	Service hole bolt	_			assembly (intake side)
< <c>></c>		•	Camshaft and camshaft sprocket	< <g>></g>	>> B <<	24.	Camshaft sprocket (intake side)
			assembly (exhaust side) removal	< <g>></g>	>> B <<	25.	Camshaft (intake side)
			preparatory operation (only at				Oil feed control valve removal
			removal.)				steps
< <d>></d>	>>F<<	9.	Front camshaft bearing cap			•	Drive belt (Refer to P.11C-19)
	>>E<<	10.	Camshaft bearing	< <h>></h>		26.	Power steering oil pump
< <e>></e>	>>D<<	11.	Oil feed camshaft bearing cap				assembly
			(exhaust side)			27.	Intake oil feeder control valve
< <e>></e>	>>D<<	12.	Camshaft bearing cap (exhaust				connector connection
			side)	<< >>	>> A <<	28.	Intake oil feeder control valve
< <e>></e>	>>D<<	13.	Camshaft bearing cap (exhaust		>> A <<	29.	O-ring
			side)			30.	Exhaust oil feeder control valve
< <e>></e>	>>D<<	14.	Thrust camshaft bearing cap	_	_		connector connection
			(exhaust side)	<< >>	>> A <<	31.	Exhaust oil feeder control valve
					>> A <<	32.	O-ring

Required Special Tool:

• MB992103: Chain Tension Release Bar



REMOVAL SERVICE POINTS

<<A>> ROCKER COVER ASSEMBLY REMOVAL

Loosen the rocker cover assembly mounting bolts in the order of number shown in the figure, and remove the rocker cover assembly.

TSB Revision	





<> NUMBER 1 CYLINDER COMPRESSION TOP DEAD CENTER SETTING

Never turn the crankshaft counterclockwise.

- Turn the crankshaft clockwise so that the camshaft sprocket timing marks become horizontal to the cylinder head upper surface, and set the number 1 cylinder to the top dead center of compression. At this time, check that the crankshaft pulley timing mark is in the 0-degree angle position of the ignition timing indicator of the timing chain case assembly.
- 2. Put paint marks on both the camshaft sprocket and timing chain at the position of camshaft sprocket timing chain mating mark (circular hole.)

<<C>> CAMSHAFT AND CAMSHAFT SPROCKET ASSEMBLY (EXHAUST SIDE) REMOVAL PREPARATORY OPERATION

1. Insert a precision flat-tipped screwdriver through the service hole of the timing chain case assembly, press up the timing chain tensioner ratchet to unlock, and keep the timing chain tensioner with that state.

NOTE: Lightly press down the tail end of the precision flat-tipped screwdriver to press up the tip of the precision flat-tipped screwdriver inserted to the timing chain tensioner to unlock.

- When inserting special tool MB992103 into the timing chain case assembly inside, pay attention to the position of the timing chain to avoid damage to the timing chain and timing chain tension side guide. Do not insert the special tool MB992103 beyond its insertion guideline.
- If unlocking the timing chain tensioner is insufficient, the special tool MB992103 cannot be inserted to the insertion guideline. Do not insert the special tool MB992103 forcibly, follow Step 1 again to unlock the timing chain tensioner and insert the special tool MB992103.





Timing chain

2. With the timing chain tensioner unlocked, insert special tool MB992103 inside the timing chain case assembly along the tension side of the timing chain until the insertion guide line aligns with the upper surface of the timing chain case assembly (Figure A.)

NOTE: With the timing chain tensioner unlocked, insert the special tool MB992103 along the tension side of the timing chain, according to the special tool MB992103 top shape. The special tool MB992103 can be inserted smoothly to the position where the special tool MB992103 insertion guide line aligns with the timing chain case assembly top surface (Figure B), and the spread timing chain tension side guide can be held (Figure C.)

- 3. With the special tool MB992103 inserted up to the insertion guide line, press the special tool MB992103 against the intake side camshaft sprocket and spread and hold the timing chain tension side guide.
- 4. Remove the flat-tipped precision screwdriver unlocking the timing chain tensioner.

The timing chain may snag on by other parts. After sagging the timing chain, never rotate the crankshaft.

5. With the timing chain tension side guide spread, hook the special tool MB992103 over the hexagon part of the camshaft on the exhaust side, and turn the camshaft clockwise to apply slack to the timing chain between the camshaft sprockets.

AC506748 AC

<<D>> FRONT CAMSHAFT BEARING CAP REMOVAL

Loosen the front camshaft bearing cap mounting bolts in the order of number shown in the figure, and remove the front camshaft bearing cap.



<<E>> OIL FEEDING CAMSHAFT BEARING CAP/CAMSHAFT BEARING CAP/THRUST CAMSHAFT BEARING CAP REMOVAL

When the camshaft bearing cap mounting bolts are loosened at once, the mounting bolts jump out by the spring force and the threads are damaged. Always loosen the mounting bolts in four or five steps.

Loosen the camshaft bearing cap mounting bolts in the order of number shown in the figure in four or five steps, and remove the camshaft bearing caps.



ENGINE MECHANICAL <2.4L ENGINE> CAMSHAFT



 \odot

Timing chain $\frac{1}{2}$

assembly

MB992103

AC506749AC

<<F>> CAMSHAFT AND CAMSHAFT SPROCKET ASSEMBLY (EXHAUST SIDE) REMOVAL

 Raise slightly the transaxle side of the camshaft and camshaft sprocket assembly (exhaust side) by using the slack of the timing chain, and remove from the cam bearing.

- 2. Remove the timing chain from the camshaft and camshaft sprocket assembly (exhaust side) toward the timing chain case assembly, and remove the camshaft and camshaft sprocket assembly (exhaust side) toward the transaxle.
- 3. Remove special tool MB992103 inserted into the timing chain case assembly.



The timing chain may snag on other parts. After removing the camshaft and camshaft sprocket assembly, never rotate the crankshaft.

4. After removing the camshaft and camshaft sprocket assembly (exhaust side), hang up the timing chain with a rope to prevent the timing chain from falling into the timing chain case assembly.

TSB	Revision	



<<G>> CAMSHAFT SPROCKET/CAMSHAFT REMOVAL

Hold the hexagon part of the camshaft with a monkey wrench. Loosen the camshaft sprocket mounting bolt and remove the camshaft sprocket from the camshaft.

<<H>> POWER STEERING OIL PUMP ASSEMBLY REMOVAL

- 1. With the hose installed, remove the power steering oil pump assembly from the bracket.
- 2. Tie the removed power steering oil pump assembly with a string at a position where it will not interfere with the removal and installation of oil feed control valve.

<<I>> OIL FEEDER CONTROL VALVE REMOVAL

After removal of the oil feeder control valve, be careful to prevent dust from getting into the oil passage in the cylinder head.

INSTALLATION SERVICE POINTS

>>A<< O-RING/OIL FEEDER CONTROL VALVE INSTALLATION

When installing the oil feeder control valve, be careful to avoid damage to the O-ring.

Apply engine oil to the O-ring of the oil feeder control valve and install the oil feeder control valve to the cylinder head.

>>B<< CAMSHAFT/CAMSHAFT SPROCKET INSTALLATION

1. Use a monkey wrench to secure the hexagon part of the camshaft in the same manner as removal.



Camshaft sprocket Camshaft sprocket bolt Camshaft sprocket bolt AC607720AB



- 2. Apply an adequate and minimum amount of engine oil to the camshaft and camshaft sprocket as shown in the figure.
- 3. Install the camshaft sprocket to the camshaft.
- 4. Apply an adequate and minimum amount of engine oil to the camshaft sprocket mounting bolt.
- 5. Tighten the camshaft sprocket mounting bolt to the specified torque.

Tightening torque: 59 \pm 5 N· m (44 \pm 3 ft-lb)

>>C<< CAMSHAFT AND CAMSHAFT SPROCKET ASSEMBLY (INTAKE SIDE) INSTALLATION

- 1. Align the intake side paint mark of the timing chain which was put at removal with the paint mark of the intake side camshaft sprocket, and install the camshaft sprocket to the timing chain.
- 2. Install the camshaft and camshaft sprocket assembly (intake side) to the cylinder head.

>>D<< THRUST CAMSHAFT BEARING CAP/CAMSHAFT BEARING CAP/OIL FEEDING CAMSHAFT BEARING CAP/CAMSHAFT BEARING INSTALLATION

- 1. Install the camshaft bearing caps to the cylinder head. NOTE: Because the thrust camshaft bearing cap and camshaft bearing cap are the same in shape, check the bearing cap number and additionally its symbol to identify the intake and exhaust sides for correct installation.
- 2. Tighten each camshaft bearing cap mounting bolts to the specified torque in the order of number shown in the figure in two or three steps.

```
Tightening torque: 12 \pm 1 N\cdot m (107 \pm 8 in-lb)
```





TSB Revision	

>>E<< CAMSHAFT BEARING/CAMSHAFT AND CAMSHAFT SPROCKET ASSEMBLY (EXHAUST SIDE) INSTALLATION

- Be careful not to drop the camshaft bearing.
- When installing the camshaft and camshaft sprocket assembly (exhaust side), be careful not to let the camshaft bearing which is installed to the front cam bearing cap deviate from its position.
- When replacing the camshaft bearing, according to the identification mark of front camshaft bearing cap in the table below, select a camshaft bearing with the corresponding size. Note that the identification mark of camshaft bearing is stamped on the place shown in the figure.

Front camshaft bearing cap		Camshaft bearing
Identification mark	Journal diameter mm (in)	dentification mark
1	40.000 - 40.008 (1.5748 - 1.5751)	1
2	40.008 - 40.016 (1.5751 - 1.5754)	2
3	40.016 - 40.024 (1.5754 - 1.5757)	3





ENGINE MECHANICAL <2.4L ENGINE> CAMSHAFT



2. In the same manner as removal, insert the precision flat-tipped screwdriver through the service hole of the timing chain case assembly, press up the ratchet of timing chain tensioner to unlock, and hold the unlocked timing chain tensioner.

NOTE: Lightly press down the tail end of the precision flat-tipped screwdriver to press up the tip of the precision flat-tipped screwdriver inserted to the timing chain tensioner to unlock.

- When inserting special tool MB992103 into the timing chain case assembly, pay attention to the position of the timing chain to avoid damage to the timing chain and timing chain tension side guide. Do not insert the special tool MB992103 beyond its insertion guideline.
- If unlocking the timing chain tensioner is insufficient, the special tool MB992103 cannot be inserted to the insertion guideline. Do not insert the special tool MB992103 forcibly, follow Step 2 again to unlock the timing chain tensioner and insert the special tool MB992103.



ENGINE MECHANICAL <2.4L ENGINE> CAMSHAFT



3. With the timing chain tensioner unlocked, insert special tool MB992103 inside the timing chain case assembly along the tension side of the timing chain until the insertion guide line aligns with the upper surface of the timing chain case assembly (Figure A.)

NOTE: With the timing chain tensioner unlocked, insert the special tool MB992103 along the tension side of the timing chain, according to the special tool MB992103 top shape. The special tool MB992103 can be inserted smoothly to the position where the special tool MB992103 insertion guide-line aligns with the timing chain case assembly top surface, and the spread timing chain tension side guide can be hold.

- 4. With the special tool inserted up to the insertion guide line, press the special tool MB992103 against the intake side camshaft sprocket (Figure B) and spread and hold the timing chain tension side guide (Figure C.)
- 5. Remove the flat-tipped precision screwdriver unlocking the timing chain tensioner.
- 6. Pull up the camshaft and camshaft sprocket assembly (exhaust side) mounting area of the timing chain (Figure D) to provide allowance for easy installation of the camshaft and camshaft sprocket assembly (exhaust side) to the timing chain.

When installing the camshaft and camshaft sprocket assembly (exhaust side), be careful not to let the camshaft bearing which is installed to the front cam bearing deviate from its position.

- 7. Align the exhaust side paint mark of the timing chain which was put at removal with the paint mark of the exhaust side camshaft sprocket, and install the timing chain to the camshaft sprocket.
- 8. Install the camshaft and camshaft sprocket assembly (exhaust side) to the cylinder head.
- 9. Remove the special tool MB992103 inserted into the timing chain case assembly inside.

AC506752AB


φ 4 mm φ 4 mm 🕻 🗄 0.14 in ିତ \bigcirc Timing chain case assembly AC506753AF 13 14 18 9 16 3 10 Engine front AC506743AE

Cylinder head

>>F<< FRONT CAMSHAFT BEARING CAP INSTALLATION

When the mounting bolts are tightened with the front camshaft bearing cap tilted, the front camshaft bearing cap is damaged. Install the front camshaft bearing cap properly to the cylinder head and camshaft.

1. Install the front camshaft bearing cap to the cylinder head, and temporarily tighten the front camshaft bearing cap mounting bolts to the specified torque in the order of the figure (1.)

Tightening torque: 17 \pm 3 N \cdot m (13 \pm 2 ft-lb)

2. Tighten the front camshaft bearing cap mounting bolts again to the specified torque in the order of the figure (2.)

Tightening torque: 30 \pm 2 N \cdot m (22 \pm 1 ft-lb)

3. After the front camshaft bearing cap installation, check that the paint markings of the camshaft sprocket and the timing chain and the timing mark of the crankshaft pulley and the 0-degree angle position of ignition timing indicator are aligned respectively.

>>G<< ROCKER COVER ASSEMBLY INSTALLATION

1. Wipe off the sealant on the mating surface of the rocker cover assembly and cylinder head and timing chain case assembly, and degrease the surface where the sealant is applied.

After the installation, until a sufficient period of time (one hour or more) elapses, do not apply the oil or water to the sealant application area or start the engine.

2. Apply sealant to the joint between the cylinder head and timing chain case assembly as shown in the figure and install the rocker cover assembly to the cylinder head.

Specified sealant: Three bond 1217G or equivalent

NOTE: Install the rocker cover assembly immediately after applying sealant.

3. Tighten the rocker cover assembly mounting bolts to the specified torque in the order of number shown in the figure.

```
Tightening torque: 3.0 \pm 1.0 N \cdot\, m (27 \pm 8 in-lb)
```

4. Tighten again the rocker cover assembly mounting bolts to the specified torque in the order of number shown in the figure.

Tightening torque: 5.5 \pm 0.5 N \cdot m (49 \pm 4 in-lb)



VALVE STEM SEAL

REMOVAL AND INSTALLATION

vice – Engine Oil Replacement P.12-5.)

Engine Oil Pan Removal (Refer to P.11C-46.)

Timing Chain Removal (Refer to P.11C-64.)

M1112008100966

٠

*Remove and assemble the marked parts in each cylinder unit.

Side Cover (RH) Removal (Refer to GROUP 51, Under

Engine Oil Draining (Refer to GROUP 12, On-vehicle Ser-

Rocker Cover Assembly Removal (Refer to P.11C-24.)

Pre-removal OperationEngine Room Under Cover Front A, B and Engine Room

Cover P.51-20.)

- Post-installation Operation
- Timing Chain Installation (Refer to P.11C-64.)
- Engine Oil Pan Installation (Refer to P.11C-46.)
- Valve Clearance Check (Refer to P.11C-11.)
- Rocker Cover Assembly Installation (Refer to P.11C-24.)
- Engine Oil Refilling (Refer to GROUP 12, On-vehicle Service –Engine Oil Replacement P.12-5.)
- Engine Room Under Cover Front A, B and Engine Room Side Cover (RH) Installation (Refer to GROUP 51, Under Cover P.51-20.)



Removal steps (Continued)

- 13. Camshaft and camshaft sprocket assembly (intake side)
- 14. Spark plug
- <<**C**>> >>**C**<< 15. Valve tappet
- <<D>>> >>B<< 16. Valve spring retainer lock
 - 17. Valve spring retainer
 - 18. Valve spring
- <<E>>> >> A<< 19. Valve stem seal

Required Special Tools:

- MD998772: Valve Spring Compressor
- MB992089: Retainer Holder C
- MB992090: Retainer Holder Attachment
- MB992085: Valve Stem Seal Pliers
- MD998737: Valve Stem Seal Installer

REMOVAL SERVICE POINTS

<<A>> FRONT CAMSHAFT BEARING CAP REMOVAL

Be careful not to drop the camshaft bearing.

Loosen the front camshaft bearing cap mounting bolts in the order of number shown in the figure, and remove the front camshaft bearing cap.



<> OIL FEEDING CAMSHAFT BEARING CAP/CAMSHAFT BEARING CAP/THRUST CAMSHAFT BEARING CAP REMOVAL

When the camshaft bearing cap mounting bolts are loosened at once, the mounting bolts jump out by the spring force and the threads are damaged. Always loosen the mounting bolts in four or five steps.

Loosen the camshaft bearing caps mounting bolts in the order of number shown in the figure in four or five steps, and remove the camshaft bearing caps.



<<C>> VALVE TAPPET REMOVAL

- Do not use pliers or other tools to remove the valve tappets. Always remove them by hand.
- When reusing the removed valve tappet, it has to be installed in the same position as before. Be sure to put a tab that shows the original installation position on the valve tappet when storing it.

Remove all of the valve tappets by hand.



TSB Revision	
--------------	--



<<D>> VALVE SPRING RETAINER LOCK REMOVAL

1. Screw in special tool MB992090 to special tool MD998772 and assemble special tool MB992089.

When removing the valve spring retainer lock, leave the piston of the cylinder in the TDC (Top Dead Center) position. The valve may fall into the cylinder if the piston is not properly in the TDC position.

2. Install special tool MD998772 (with special tools MB992090 and MB992089 attached) to the cylinder head and compress the valve spring. Then, remove the valve spring retainer lock.



<<E>> VALVE STEM SEAL REMOVAL

Use special tool MB992085 to grip the base of the stem seal (where the outside diameter is larger) securely, and remove it by twisting it to the left and right.

INSTALLATION SERVICE POINTS

>>A<< VALVE STEM SEAL INSTALLATION

- Valve stem seals cannot be reused.
- Do not damage the wall of the tappet hole when installing the valve stem seal.
- Special tool MD998737 must be used to install the valve stem seal. Improper installation of the valve stem seal could result in oil leaking past the valve guide.
- 1. Apply a small amount of engine oil to the press-fit part and lip part of the new valve stem seal.



2. Use special tool MD998737 to press-fit a new valve stem seal in the valve guide using the valve stem area as a guide.



>>B<< VALVE SPRING RETAINER LOCK INSTALLATION

In the same manner as removal, use special tool MD998772 (with special tools MB992090 and MB992089 attached) to compress the valve spring, and install the valve spring retainer lock.



>>C<< VALVE TAPPET INSTALLATION

1. Apply a small amount of engine oil to the valve tappets.

- Do not use pliers or other tools to install the valve tappets. Always install them by hand.
- Be sure to install the valve tappets in the same position as before.
- 2. Install the valve tappet to the cylinder head.



TSB Revision	
--------------	--



>>D<< THRUST CAMSHAFT BEARING CAP/CAMSHAFT BEARING CAP/OIL FEEDING CAMSHAFT BEARING CAP INSTALLATION

- 1. Install the camshaft bearing caps to the cylinder head. NOTE: Because the thrust camshaft bearing cap and camshaft bearing cap are the same in shape, check the cap number and additionally its symbol to identify the intake and exhaust sides for correct installation.
- 2. Tighten each camshaft bearing cap mounting bolts to the specified torque in the order of number shown in the figure in two or three steps.

Tightening torque: $12 \pm 1 \text{ N} \cdot \text{m}$ (107 ± 8 in-lb)



ГSВ	Revision	

>>E<< CAMSHAFT BEARING/CAMSHAFT AND CAMSHAFT SPROCKET ASSEMBLY (EXHAUST SIDE) INSTALLATION

- Be careful not to drop the camshaft bearing.
- When installing the camshaft and camshaft sprocket assembly (exhaust side), be careful not to let the camshaft bearing which is installed to the front cam bearing deviate from its position.

When replacing the camshaft bearing, according to the identification mark of front camshaft bearing cap in the table below, select a camshaft bearing with the corresponding size. Note that the identification mark of camshaft bearing is stamped on the place shown in the figure.

Front camshat	t bearing cap	Camshaft bearing identification mark		
Identification mark	Journal diameter mm (in)			
1	40.000 - 40.008 (1.5748 - 1.5751)	1		
2	40.008 - 40.016 (1.5751 - 1.5754)	2		
3	40.016 - 40.024 (1.5754 - 1.5757)	3		





>>F<< FRONT CAMSHAFT BEARING CAP INSTALLATION

When the mounting bolts are tightened with the front camshaft bearing cap tilted, the front camshaft bearing cap is damaged. Install the front camshaft bearing cap properly to the cylinder head and camshaft.

1. Install the front camshaft bearing cap to the cylinder head, and temporarily tighten the front camshaft bearing cap mounting bolts to the specified torque in the order of the figure (1.)

Tightening torque: 17 \pm 3 N \cdot m (13 \pm 2 ft-lb)

2. Tighten the front camshaft bearing cap mounting bolts again to the specified torque in the order of the figure (2.)

Tightening torque: 30 \pm 2 N \cdot m (22 \pm 1 ft-lb)





OIL PAN

REMOVAL AND INSTALLATION

M1112002802769

Pre-removal Operation	Post-installation Operation
Engine Room Under Cover Front A, B and Engine Room	 Drive Belt Installation (Refer to P.11C-19.)
Side Cover (RH) Removal (Refer to GROUP 51, Under	• Engine Oil Refilling (Refer to GROUP 12, On-vehicle Ser-
Cover P.51-20.)	vice – Engine Oil Replacement P.12-5.)
Engine Oil Draining (Refer to GROUP 12, On-vehicle Ser-	Engine Room Under Cover Front A, B and Engine Room
vice – Engine Oil Replacement P.12-5.)	Side Cover (RH) Installation (Refer to GROUP 51, Under

- Drive Belt Removal (Refer to P.11C-19.)
- Cover P.51-20.)



Removal steps

- 1. A/C compressor and clutch connector connection <<**A**>> >>**C**<< 2. A/C compressor and clutch
 - assembly A/C compressor bracket A 3.
- <<**B**>> >>**A**<< 7.

AC803678AB

Removal steps (Continued)

- 4. A/C compressor bracket B
- 5. Engine oil pan drain plug
- >>**B**<< 6. Engine oil pan drain plug gasket
 - Engine oil pan

Required Special Tool:

MD998727: Oil Pan FIPG Cutter

REMOVAL SERVICE POINTS

<<A>> A/C COMPRESSOR AND CLUTCH ASSEM-BLY REMOVAL

- 1. Remove the A/C compressor and clutch assembly together with the hose from the bracket.
- 2. Tie the removed A/C compressor and clutch assembly with a string at a position where they will not interfere with the removal and installation of engine oil pan.

<> ENGINE OIL PAN REMOVAL

1. Remove the engine oil pan mounting bolts.

Do not forcibly drive in special tool MD998727 to avoid damage to the engine oil pan seal surface of cylinder block assembly.

- 2. Insert special tool MD998727 from the engine oil pan removal groove of the cylinder block assembly.
- 3. Lightly tap the special tool MD998727 with a hammer to slide the engine oil pan seal surface, cut off the liquid gasket, and remove the engine oil pan.







TSB	Revision	

¢ 2.5 mm (¢ 0.1in)





INSTALLATION SERVICE POINTS

>>A<< ENGINE OIL PAN INSTALLATION

- 1. Remove all the traces of sealant adhering to the engine oil pan and cylinder block assembly using a remover or others. Then, degrease them.
- 2. Apply the sealant without any gap to the mating surface of engine oil pan as shown in the figure, and install the engine oil pan to the cylinder block assembly.

Specified sealant: Three bond 1217G or equivalent

NOTE: Install the engine oil pan immediately after applying sealant.

After the installation, until a sufficient period of time (one hour or more) elapses, do not apply the oil or water to the sealant application area or start the engine.

3. Tighten the engine oil pan mounting bolts to the specified torque.

Tightening torque: M6: 10 ±2 N· m (89 ±17 in-lb) M8: 29 ±2 N· m (21 ±1 ft-lb)

>>B<< ENGINE OIL PAN DRAIN PLUG GASKET INSTALLATION

Replace the engine oil pan drain plug gasket with a new one. Install the new engine oil pan drain plug gasket in the direction shown in the illustration.

>>C<< A/C COMPRESSOR AND CLUTCH ASSEMBLY INSTALLATION

Tighten A/C compressor and clutch assembly mounting bolts to the specified torque in the order of number shown in the illustration.

Tightening torque: 23 ± 6 N· m (17 ± 4 ft-lb)

INSPECTION

- Check the engine oil pan for cracks.
- Check the engine oil pan sealant-coated surface for damage and deformation.

TSB Revision

M1112002900834

CRANKSHAFT OIL SEAL

REMOVAL AND INSTALLATION



Required Special Tools:

- MB991883: Flywheel Stopper
- MD998718: Crankshaft Rear Oil Seal Installer
- MB991448: Bush Remover And Installer Base

REMOVAL SERVICE POINT

<<A>> FLYWHEEL BOLT <M/T>/DRIVE PLATE BOLT <CVT> REMOVAL

Fix the flywheel assembly using special tool MB991883, and loosen the flywheel bolts <M/T.>

Fix the drive plate using special tool MB991883, and loosen the drive plate bolts <CVT.>

Cylinder block



INSTALLATION SERVICE POINTS

>>A<< CRANKSHAFT REAR OIL SEAL INSTAL-LATION

- 1. Apply a small amount of engine oil to the entire inner diameter of the crankshaft rear oil seal lip.
- 2. Using special tool MD998718, press in the crankshaft rear oil seal up to the cylinder block end surface.

>>B<< DRIVE PLATE <CVT>/ADAPTER PLATE <CVT>/DRIVE PLATE BOLT <CVT>/FLYWHEEL ASSEMBLY <M/T>/FLYWHEEL BOLT <M/T> INSTALLATION

- Remove the sealant, engine oil, and other adhering materials from the drive plate installation face, the crankshaft screw hole and drive plate bolts <CVT.> Remove the sealant, engine oil, and other adhering materials from the flywheel assembly installation face, the crankshaft screw hole and flywheel bolts <M/T.>
- 2. Install the drive plate and drive plate adapter plate to the crankshaft <CVT.>

Install the flywheel assembly to the crankshaft <M/T.>





 Use special tool MB991883 to secure the drive plate in the same manner as removal <CVT.>

Use special tool MB991883 to secure the flywheel assembly in the same manner as removal <M/T.>

 Apply a small amount of engine oil to the screw holes of the crankshaft and the bearing surface of the drive plate bolts <CVT.>

Apply a small amount of engine oil to the screw holes of the crankshaft and the bearing surface of the flywheel bolts <M/T.>

5. Apply specified sealant to the drive plate bolts <CVT> or flywheel bolts <M/T> threads.

Specified sealant: Three bond 1324 or exact equivalent

- Tighten the drive plate bolts <CVT> or flywheel bolts <M/T> to the specified torque in the order shown in the illustration.
 Tightening torque: 40 N ⋅ m (30 ft-lb)
- Tighten the drive plate bolts <CVT> or flywheel bolts <M/T> to the specified torque again in the order shown in the illustration.

Tightening torque: 130 N· m (96 ft-lb)

>>C<< CRANKSHAFT FRONT OIL SEAL INSTALLATION

1. Apply a small amount of engine oil to the entire inner diameter of the crankshaft front oil seal lip.

When installing the crankshaft front oil seal, be careful to avoid damage to the crankshaft front oil seal.

2. Using special tool MB991448, press in the crankshaft front oil seal up to the chamfered surface of timing chain case.



AC609796AB

CYLINDER HEAD GASKET

REMOVAL AND INSTALLATION

M1112004004130



AC702470AC

Removal steps (Continued)

- Emission vacuum hose connection
- 10. Brake booster vacuum hose
- 13. Cylinder head cover PCV hose
- connection

>>**G**<< 8. O-ring

ENGINE MECHANICAL <2.4L ENGINE> CYLINDER HEAD GASKET



		•	Valve timing chain (Refer to P.11C-64)	< <d>>></d>	>>D<< >>C<<	20. 21.	Thrust camshaft bearing cap Camshaft and camshaft sprocket
< <c>> <<d>> <<d>> <<d>></d></d></d></c>	>>E<< >>C<< >>D<< >>D<< >>D<<	15. 16. 17. 18. 19.	Front camshaft bearing cap Camshaft bearing Oil feeding camshaft bearing cap Camshaft bearing cap Camshaft bearing cap	< <e>> <<e>></e></e>	>>C<< >>B<< >>B<< >>A<< >>A<<	22. 23. 24. 25. 26.	assembly Camshaft bearing Cylinder head bolt Cylinder head bolt assembly Cylinder head assembly Cylinder head gasket

Required Special Tools:

- MB991454: Engine Hanger Balancer
- MB991895: Engine Hanger
- MB991928: Engine Hanger

REMOVAL SERVICE POINTS

<<A>> RADIATOR UPPER HOSE/RADIATOR LOWER HOSE DISCONNECTION

Make mating marks on the radiator hose and the hose clamp as shown to install them in the original position. Then, remove them.



<> FUEL HIGH-PRESSURE HOSE DISCONNECTION

1. Remove the stopper of the fuel high-pressure hose.



Retainer AC301861AC

2. Raise the retainer of the fuel high-pressure hose and pull out the fuel high-pressure hose in the direction shown in the figure.

NOTE: If the retainer is released, install it securely after removing the fuel high-pressure hose.

<<C>> FRONT CAMSHAFT BEARING CAP REMOVAL

1. Temporarily install the engine oil pan which was removed at the timing chain removal (Refer to P.11C-46.)

When supporting the engine and transaxle assembly with a garage jack, be careful not to deform the engine oil pan.

2. Place a garage jack against the engine oil pan with a piece of wood in between to support the engine and transaxle assembly.

TSB Revision	

11C-56

ENGINE MECHANICAL <2.4L ENGINE> CYLINDER HEAD GASKET



3. Remove special tool MB991454, MB991928 or MB991895 which was installed for supporting the engine and transaxle assembly when the timing chain was removed.



Be careful not to drop the camshaft bearing.

- Front camshaft bearing cap
- 4. Loosen the front camshaft bearing cap mounting bolts in the order of number shown in the figure, and remove the front camshaft bearing cap.

<<D>> OIL FEEDING CAMSHAFT BEARING CAP/CAMSHAFT BEARING CAP/THRUST CAMSHAFT BEARING CAP REMOVAL

When the camshaft bearing cap mounting bolts are loosened at once, the mounting bolts jump out by the spring force and the threads are damaged. Always loosen the mounting bolts in four or five steps.

Loosen the camshaft bearing cap mounting bolts in the order of number shown in the figure in four or five steps, and remove the camshaft bearing caps.





<<E>> CYLINDER HEAD BOLT/CYLINDER HEAD BOLT ASSEMBLY REMOVAL

Loosen and remove the cylinder head bolts in two or three steps in the order of number shown in the figure.

TSB Revision	
--------------	--

INSTALLATION SERVICE POINTS

>>A<< CYLINDER HEAD GASKET/CYLINDER HEAD ASSEMBLY INSTALLATION

Do not allow any foreign materials get into the coolant passages, oil passages and cylinder.

1. Remove the sealant and grease on the top surface of cylinder block and on the bottom surface of the cylinder head. Then, degrease the sealant application surface.



 ϕ 2 mm or ϕ 3 mm

Cylinder block

(o 0.08 in or o 0.12 in) ≜

2. Apply the sealant to the top surface of cylinder block as shown in the figure.

Specified sealant: Three bond 1217G or equivalent

3. Within three minutes after the sealant application, install the cylinder head gasket to the cylinder block.

NOTE: When the cylinder gasket is installed to the cylinder block, check that the sealant is securely applied to the bead line of the cylinder head gasket.

4. Apply the sealant to the top surface of cylinder head gasket as shown in the figure.

Specified sealant: Three bond 1217G or equivalent

After the installation, until a sufficient period of time (one hour or more) elapses, do not apply the oil or water to the sealant application area or start the engine.

5. Within three minutes after the sealant application, install the cylinder head assembly.



AC511063AD

>>B<< CYLINDER HEAD BOLT ASSEMBLY/CYLINDER HEAD BOLT INSTALLATION

- 1. Replace cylinder head bolts with a new ones.
- 2. For two cylinder head bolts of the timing chain side, the washer can be removed from the bolt. Install the washer, with its sag facing upward, to the cylinder head bolts.
- 3. Apply a small amount of engine oil to the cylinder head bolt threads and the washers.
- 4. Tighten the cylinder head bolts by the following procedure (plastic region angular tightening method.)
 - (1) Tighten the cylinder head bolts to the specified torque in the order of number shown in the figure.

Tightening torque: $35 \pm 2 \text{ N} \cdot \text{m}$ (26 ± 1 ft-lb)

- When the tightening angle is smaller than the specified tightening angle, the appropriate tightening capacity cannot be secured.
- When the tightening angle is larger than the specified tightening angle, remove the cylinder head bolt to start from the beginning again according to the procedure.
- (2) Apply paint marks to the head of cylinder head bolt and the cylinder head.
- (3) Tighten the cylinder head bolt to 90 degrees angle in the tightening order. Additionally tighten to 90 degrees angle, and check that the paint mark on the cylinder head bolt is aligned with the paint mark on the cylinder head.





ГSВ	Revision	

Front camshaft bearing cap Identification mark



>>C<< CAMSHAFT BEARING/CAMSHAFT AND CAMSHAFT SPROCKET ASSEMBLY INSTALLATION

- Be careful not to drop the camshaft bearing.
- When installing the camshaft and camshaft sprocket assembly (exhaust side), be careful not to let the camshaft bearing which is installed to the front cam bearing deviate from its position.

When replacing the camshaft bearing, according to the identification mark of front camshaft bearing cap in the table below, select a camshaft bearing with the corresponding size. Note that the identification mark of camshaft bearing is stamped on the place shown in the figure.

Front camsha	ft bearing cap	Camshaft bearing
Identification mark	Journal diameter mm (in)	dentification mark
1	40.000 - 40.008 (1.5748 - 1.5751)	1
2	40.008 - 40.016 (1.5751 - 1.5754)	2
3	40.016 - 40.024 (1.5754 - 1.5757)	3



>>D<< THRUST CAMSHAFT BEARING CAP/CAMSHAFT BEARING CAP/OIL FEEDING CAMSHAFT BEARING CAP INSTALLATION

- 1. Install the camshaft bearing caps to the cylinder heads. NOTE: Because the thrust camshaft bearing cap and camshaft bearing cap are the same in shape, check the bearing cap number and additionally its symbol to identify the intake and exhaust sides for correct installation.
- 2. Tighten each camshaft bearing cap mounting bolts to the specified torque in the order of number shown in the figure in two or three steps.

Tightening torque: $12 \pm 1 \text{ N} \cdot \text{m}$ (107 ± 8 in-lb)

>>E<< FRONT CAMSHAFT BEARING CAP INSTALLATION

When the mounting bolts are tightened with the front camshaft bearing cap tilted, the front camshaft bearing cap is damaged. Install the front camshaft bearing cap properly to the cylinder head and camshaft.

1. Install the front camshaft bearing cap to the cylinder head, and temporarily tighten the front camshaft bearing cap mounting bolts to the specified torque in the order of the figure (1.)

Tightening torque: 17 \pm 3 N[.] m (13 \pm 2 ft-lb)

2. Tighten the front camshaft bearing cap mounting bolts again to the specified torque in the order of the figure (2.)

Tightening torque: 30 \pm 2 N· m (22 \pm 1 ft-lb)



11C-62







- Install special tool MB991454, MB991928 or MB991895 which was installed for supporting the engine and transaxle assembly when the timing chain was removed (Refer to P.11C-64.)
- 4. Remove the garage jack which supports the engine and transaxle assembly.
- 5. Remove the engine oil pan installed temporarily.





>>F<< FUEL HIGH-PRESSURE HOSE CONNECTION

After connecting the fuel high-pressure hose, slightly pull it in the pull-out direction to check that it is installed firmly. In addition, check that there is approximately 3mm (0.12 inch) play. After the check, install the stopper securely. Apply a small amount of engine oil to the fuel line pipe, and install the fuel high-pressure hose.

TSB Revision	



>>G<< O-RING INSTALLATION

Avoid adhesion of engine oil or grease to the O-ring. Fit the O-ring in the water pump inlet pipe groove, wet the O-ring circumference or the pipe mounting area inner wall, and then insert the O-ring.

>>H<< RADIATOR LOWER HOSE/RADIATOR UPPER HOSE CONNECTION

- 1. Insert radiator hose as far as the projection of the water inlet fitting or water outlet fitting.
- 2. Align the mating marks on the radiator hose and hose clamp, and then connect the radiator hose.



	Deviation
ISB	Revision

TIMING CHAIN

REMOVAL AND INSTALLATION

M1112007201286



Required Special Tools:

- MB991454: Engine Hanger Balancer
- MB991895: Engine Hanger

- MB991928: Engine Hanger
- MB991448: Bush Remover and Installer Base

REMOVAL SERVICE POINTS

<<A>> CRANKSHAFT PULLEY REMOVAL

When removing the crankshaft pulley, slightly loosen the water pump pulley mounting bolts before removal of the drive belt.

<> POWER STEERING OIL PUMP ASSEMBLY REMOVAL

- 1. With the hose installed, remove the power steering oil pump assembly from the bracket.
- 2. Tie the removed power steering oil pump assembly with a string at a position where it will not interfere with the removal and installation of timing chain.

<<C>> ENGINE AND TRANSAXLE ASSEMBLY HOLDING

Install a special tool for holding the engine and transaxle assembly.

- 1. <Special tool MB991928 is used>
 - (1) Assemble the special tool MB991928. Set the following parts on the base hanger.
- Slide bracket (HI)
- Foot x 4 (standard) (MB991932)
- Joint x 2 (90) (MB991930)
- (2) Set the foot of the special tool as shown in the figure.
 - NOTE: Slide the slide bracket (HI) to adjust the engine hanger balance.





(3) Mount special tool MB991454 to the power steering oil pump bracket and engine hanger, and set it to special tool MB991928 to support the engine and transaxle assembly.

TSB Revision	







- 2. <Special tool MB991895 is used>
 - (1) Set the foot of special tool MB991895 as shown in the figure.

NOTE: Slide the foot to adjust the engine hanger balance.

(2) Mount special tool MB991454 to the power steering oil pump bracket and the engine hanger, and set it to special tool MB991895 to support the engine and transaxle assembly.

<<D>> TIMING CHAIN CASE ASSEMBLY REMOVAL

If the adhesive strength of sealant on the timing chain case assembly is so strong that the boss may be damaged by peeling off, do not peel it off forcibly.

1. After removing the timing chain case assembly mounting bolts, slightly pry the boss of the timing chain case assembly shown in the figure using a flat-tipped screwdriver, and remove the timing chain case assembly from the cylinder head and cylinder block.



Timing chain

Boss 년 셋 Ø

> 2. If the sealant cannot be peeled off easily, insert a wooden hammer shank into the timing chain case assembly inside as shown in the figure, pry slightly, and remove the timing chain case assembly from the cylinder head and cylinder block.

TSB	Revision	





<<E>>> TIMING CHAIN TENSIONER REMOVAL

1. Temporarily install the crankshaft pulley to the crankshaft.

Never turn the crankshaft counterclockwise.

2. Turn the crankshaft clockwise to align the sprocket timing marks as shown in the figure and set the number 1 cylinder to the top dead center of compression stroke.

NOTE: At this time, it is not necessary that the link plate (orange or blue) of the timing chain always aligns with each sprocket timing mark.

3. Remove the crankshaft pulley installed temporarily.

- 4. Using a flat-tipped precision screwdriver, release the ratchet of timing chain tensioner.
- 5. Compress the plunger of timing chain tensioner and insert hard wire (such as piano wire) or the L-shaped hexagon wrench [1.5 mm(0.05 inch)] to fix the plunger of the timing chain tensioner.
- 6. Remove the timing chain tensioner.



Mating mark

Link plate (blue)

AC506772AR

INSTALLATION SERVICE POINTS

>>A<< TIMING CHAIN INSTALLATION

1. Set the timing marks of the camshaft sprockets and the crankshaft sprocket as shown in the figure.

2. Align each sprocket timing chain mating marks with the link plate (orange or blue) of timing chain to avoid slack of the timing chain tension side, and install the timing chain to the sprockets.

|--|



O

L-shaped

hexagon wrench

Timing chain tensioner

>>B<< TIMING CHAIN TENSIONER INSTALLATION

1. Check that the sprocket timing chain mating marks align with the link plates (orange or blue) of the timing chain, and install the timing chain tensioner to the cylinder block.

2. Remove the hard wire or L-shaped hexagon wrench fixing the plunger of the timing chain tensioner to apply tension to the timing chain.

>>C<< CRANKSHAFT FRONT OIL SEAL INSTALLATION

1. Apply a small amount of engine oil to the entire inner diameter of the crankshaft front oil seal lip.

When installing the crankshaft front oil seal, be careful to avoid damage to the crankshaft front oil seal.

2. Using special tool MB991448, press in the crankshaft front oil seal up to the chamfered surface of timing chain case.



TSB Revision

AC506773 AE

>>D<< TIMING CHAIN CASE ASSEMBLY INSTALLATION

- Be sure to remove the sealant remaining in the mounting hole, O-ring groove, and gap between parts.
- After degreasing with degreasing agent, check that there is no oil on the surface where the sealant is applied.
- After degreasing with degreasing agent, never touch the degreased area with fingers.
- 1. Remove sealant from the timing chain case assembly and the timing chain case assembly mounting surface of the cylinder block and the cylinder head, and degrease the surface where the sealant is applied.
- 2. Remove all the sealant adhering to the gasket between the cylinder head and cylinder block (three-surface aligned part.) Then, degrease the surfaces.
- 3. As for the three-surface aligned part that is indicated in Step 2 above, the engine oil oozes from the cylinder head gasket. Thus, quickly apply the sealant to it after degreasing.
- 4. Apply a bead of the sealant to the timing chain case assembly mounting surface. The bead diameter should be $2.5 \pm 0.5 \text{ mm} (0.1 \pm 0.02 \text{ inch.})$ Overlap the part "A" with the diameter of $4.5 \pm 0.5 \text{ mm} (0.18 \pm 0.02 \text{ inch})$ or $2.5 \pm 0.5 \text{ mm} (0.1 \pm 0.02 \text{ inch})$ as shown in the figure, and apply the sealant.

Specified sealant: Three bond 1217G or equivalent

- If the sealant contacts any other part during installation of the timing chain case assembly, apply sealant again before installing the timing chain case assembly.
- After the installation, until a sufficient period of time (one hour or more) elapses, do not apply the oil or water to the sealant application area or start the engine.
- 5. Install the timing chain case assembly to the cylinder block and cylinder head so that the sealant does not contact other parts.

NOTE: Install the timing chain case assembly immediately after applying sealant.



TSB Revision	

ENGINE MECHANICAL <2.4L ENGINE> TIMING CHAIN



6. Insert the bolts to the timing chain case assembly as shown, and tighten them to the specified torque.

Bolt (symbol)	Thread diameter x Length mm	Tightening torque
Flange bolt (A)	M6 × 25	10 ±2 N· m (89 ± 17 in-lb)
Flange bolt (B)	M8 × 28	24 ±4 N· m (18 ±2 ft-lb)
Bolt (C)	M6 × 25	10 ±2 N· m (89 ± 17 in-lb)

>>E<< WATER PUMP PULLEY INSTALLATION

Temporarily tighten the water pump pulley mounting bolts. Then, tighten them to the specified torque after the installation of drive belt.

Tightening torque: 9.0 \pm 1.0 N \cdot m (80 \pm 9 in-lb)

BALANCER TIMING CHAIN, BALANCER SHAFT AND OIL PUMP MODULE

REMOVAL AND INSTALLATION

M1112008500254



>A<< 5. Balancer timing chai >>A<< 6. Crankshaft sprocket</p>

Required Special Tool:

• MB991614: Angle Gauge
REMOVAL SERVICE POINT

<<A>> TIMING CHAIN TENSIONER REMOVAL

Securely install the plunger of the timing chain tensioner. Otherwise, it may pop out.

- Press the balancer timing chain against the timing chain tensioner, compress the plunger of the timing chain tensioner and insert hard wire (piano wire, etc.) or L-shaped hexagon wrench [1.5 mm (0.05 inch)] to fix the plunger of the timing chain tensioner.
- 2. Remove the timing chain tensioner.

INSTALLATION SERVICE POINTS

>>A<< CRANKSHAFT SPROCKET/BALANCER TIMING CHAIN/BALANCER SHAFT AND OIL PUMP MODULE INSTALLATION

- 1. When installing the new balancer shaft and oil pump module, apply oil to the oil pump in the balancer shaft and oil pump module and the balancer shaft bearing as follows.
 - (1) Clean the inside of the removed engine oil pan, and put the balancer shaft and oil pump module into the engine oil pan with its oil inlet port facing up.
 - (2) Pour new engine oil until two-thirds of the balancer shaft and oil pump module is soaked.
 - (3) Fill the new engine oil [approximately 50 cm³ (3.05 cu.in.)] into the balancer shaft and oil pump module from the oil inlet port.
 - (4) Turn the balancer shaft sprocket of the balancer shaft and oil pump module clockwise four rotations or more to apply the engine oil to the entire area of the oil pump and the balancer shaft bearing.







ΓSΒ	Revision	

11C-74

ENGINE MECHANICAL <2.4L ENGINE> BALANCER TIMING CHAIN, BALANCER SHAFT AND OIL PUMP MODULE







2. Wipe the dirt on the crankshaft sprocket and the crankshaft using a rag, and then remove the grease from the portion shown in the illustration.

NOTE: Remove grease to prevent a drop in the coefficient of friction of the pressing portion caused by adhesion of oil.

- 3. With the link marks (orange or blue) of balancer timing chain aligned with the timing marks of balancer sprocket and crankshaft sprocket, install the balancer shaft and oil pump module together with the balancer timing chain and crankshaft sprocket as one unit to the cylinder block. At this time, securely bring the balancer shaft and oil pump module into contact with the rudder frame mounting area.
- 4. Apply an adequate and minimum amount of engine oil to the threads and bearing surfaces of the balancer shaft and oil pump module mounting bolts.

5. Tighten the balancer shaft and oil pump module mounting bolts to the specified torque in the order of number shown in the figure.

Tightening torque: 20 N· m (15 ft-lb)

6. Retighten the balancer shaft and oil pump module mounting bolts to the specified torque in the order of number shown in the figure.

Tightening torque: 44 N· m (32 ft-lb)

- 7. Loosen each balancer shaft and oil pump module mounting bolts fully in the reverse sequence to that shown.
- 8. Tighten the balancer shaft and oil pump module mounting bolts again to the specified torque in the order of number shown in the figure.

Tightening torque: 20 N· m (15 ft-lb)

ENGINE MECHANICAL <2.4L ENGINE> BALANCER TIMING CHAIN, BALANCER SHAFT AND OIL PUMP MODULE



9. After tightening to the specified torque, tighten the balancer shaft and oil pump module mounting bolts to 135 degrees angle, using special tool MB991614, in the order of number shown in the figure.





>>B<< TIMING CHAIN TENSIONER INSTALLATION

- 1. Install the timing chain tensioner to the cylinder block.
- 2. Remove the hard wire or L-shaped hexagon wrench fixing the plunger of the timing chain tensioner to apply tension to the balancer timing chain.

ГSВ	Revision	

BALANCER SHAFT AND OIL PUMP MODULE

REMOVAL AND INSTALLATION

M1112008900230

AC509274 AE

Pre-removal and Post-installation Operation

- Engine Oil Pan Removal and Installation (Refer to
 - P.11C-46.)



Removal steps

<<A>> >>A<< 1. Balancer shaft and oil pump module

Required Special Tool:

• MB991614: Angle Gauge

FSB Revision

REMOVAL SERVICE POINT

<<A>> BALANCER SHAFT AND OIL PUMP MOD-ULE REMOVAL

- Never turn the crankshaft counterclockwise.
- Never turn the crankshaft after the number 1 cylinder or number 4 cylinder is set to the top dead center of compression.
- 1. Turn the crankshaft clockwise to align the timing mark of the balancer shaft sprocket with the timing mark of the balancer shaft and oil pump module, and set the number 1 cylinder or number 4 cylinder to the top dead center of compression.
- 2. Put paint mark on the balancer shaft sprocket timing mark and balancer timing chain.



L-shaped hard wire or L-shaped hexagon wrench Timing chain tensioner AC509276AB



Securely install the plunger of the timing chain tensioner. Otherwise, it may pop out.

 Press the balancer timing chain against the timing chain tensioner, compress the plunger of the timing chain tensioner and insert L-shaped hard wire (piano wire, etc.) or L-shaped hexagon wrench [1.5 mm (0.05 inch)] to the plunger fixing hole of the timing chain tensioner from under the timing chain case, and fix the plunger of the timing chain tensioner.

chain

ENGINE MECHANICAL <2.4L ENGINE> BALANCER SHAFT AND OIL PUMP MODULE



- 4. Use a wrench to remove the mounting bolt at the lower side of the balancer timing chain guide shown in the figure so that the balancer timing chain guide is unrestricted.
- 5. Support the balancer shaft and oil pump module with a hand, and remove the balancer shaft and oil pump module mounting bolts.
- 6. Remove the balancer shaft and oil pump module from the rudder frame with the balancer timing chain attached, and move it to the center of the engine.
- 7. Remove the balancer timing chain from the balancer shaft and oil pump module, and remove the balancer shaft and oil pump module.

AC509279AB

When the tooth jump of the balancer timing chain from the crankshaft sprocket occurs, the timing between the balancer shaft and the oil pump module becomes off, resulting in the abnormal engine vibration. Be sure that the tooth jump will not occur.

8. After the balancer shaft and oil pump module is removed, using a cable band, tie the balancer timing chain at the protrusion of the rudder frame to prevent the tooth jump of balancer timing chain from the crankshaft sprocket.

INSTALLATION SERVICE POINT

>>A<< BALANCER SHAFT AND OIL PUMP MOD-ULE INSTALLATION

1. When installing the new balancer shaft and oil pump module, apply engine oil to the oil pump in the balancer shaft and oil pump module and the balancer shaft bearing as follows.



ГSВ	Revision		

ENGINE MECHANICAL <2.4L ENGINE> BALANCER SHAFT AND OIL PUMP MODULE

Oil inlet oil engine oil







- (1) Clean the inside of the removed engine oil pan, and put the balancer shaft and oil pump module into the engine oil pan with its oil inlet port facing up.
- (2) Pour new engine oil until two-thirds of the balancer shaft and oil pump module is soaked.
- (3) Fill the new engine oil [approximately 50 cm³ (3.05 cu.in.)] into the balancer shaft and oil pump module from the oil inlet port.
- (4) Turn the balancer shaft sprocket of the balancer shaft and oil pump module clockwise four rotations or more to apply the engine oil to the entire area of the oil pump and the balancer shaft bearing.
- 2. Remove the cable band installed to prevent the tooth jump of the balancer timing chain from the crankshaft sprocket from the balancer timing chain.
- 3. Regarding the prevention of the tooth jump of the balancer timing chain, install the balancer shaft sprocket to the balancer timing chain with aligning the paint mark of the balancer shaft sprocket (the timing mark of the new balancer shaft and oil pump module) with that of the balancer timing chain.
- 4. With the paint mark of the balancer timing chain aligned with that of the balancer sprocket (the timing mark of the new balancer shaft and oil pump module), install the balancer shaft and oil pump module to the rudder frame. Securely bring the balancer shaft and oil pump module into contact with the rudder frame mounting area.
- 5. Apply an adequate and minimum amount of engine oil to the threads and bearing surfaces of the balancer shaft and oil pump module mounting bolts.
- 6. Tighten the balancer shaft and oil pump module mounting bolts to the specified torque in the order of number shown in the figure.

Tightening torque: 20 N· m (15 ft-lb)

7. Retighten the balancer shaft and oil pump module mounting bolts to the specified torque in the order of number shown in the figure.

Tightening torque: 44 N· m (32 ft-lb)

- 8. Loosen each balancer shaft and oil pump module mounting bolts fully in the reverse sequence to that shown.
- 9. Tighten the balancer shaft and oil pump module mounting bolts again to the specified torque in the order of number shown in the figure.

Tightening torque: 20 N· m (15 ft-lb)

TSB Revision	

ENGINE MECHANICAL <2.4L ENGINE> BALANCER SHAFT AND OIL PUMP MODULE





- 10.After tightening to the specified torque, tighten the balancer shaft and oil pump module mounting bolts to 135 degrees angle, using special tool MB991614, in the order of number shown in the figure.
- 11.Tighten the mounting bolt of the lower side of the balancer timing chain guide with the standard torque.

Tightening torque: 10 \pm 2 N \cdot m (89 \pm 17 in-lb)

12.Remove the plunger of the timing chain tensioner using the L-shaped hard wire (piano wire, etc.) or L-shaped hexagon wrench [1.5 mm (0.05 inch).]

ENGINE ASSEMBLY

REMOVAL AND INSTALLATION

M1112001005695

11C-81

When the engine assembly replacement is performed, use scan tool MB991958 to initialize the learning value (Refer to GROUP 00, Initialization Procedure for Learning Value in MFI Engine P.00-38.)

Pre-removal Operation

- Hood Removal (Refer to GROUP 42A, Hood P.42A-7.)
 Fuel Line Pressure Reduction (Refer to GROUP 13B, On-vehicle Service –How to Reduce Pressurized Fuel
- Engine Room Under Cover Front A, B and Engine Room Side Cover Removal (Refer to GROUP 51, Under Cover
- P.51-20.)Engine Coolant Draining (Refer to GROUP 14, On-vehicle
- Service –Engine Coolant Replacement P.14-26.)
 Engine Oil Draining (Refer to GROUP 12, On-vehicle Service –Engine Oil Replacement P.12-5.)
- Transmission Oil Draining (Refer to GROUP 22A, On-vehicle Service –Transmission Oil Replacement P.22A-8) <M/T.>
- Transmission Fluid Draining (Refer to GROUP 23A, On-vehicle Service –Transmission Fluid Replacement P.23A-136) <CVT.>
- Engine Upper Cover Removal (Refer to P.11C-24.)
- Exhaust Manifold Removal (Refer to GROUP 15, Exhaust Manifold P.15-26.)
- Air Cleaner Assembly Removal (Refer to GROUP 15, Air Cleaner P.15-10.)
- Battery and Battery Tray Removal (Refer to GROUP 54A, Battery P.54A-10.)
- Engine control module Removal (Refer to GROUP 13B, Engine Control Module P.13B-1022.)
- Radiator Removal (Refer to GROUP 14, Radiator P.14-53.)
- Drive Belt Removal (Refer to P.11C-19.)

Post-installation Operation

- Drive Belt Installation (Refer to P.11C-19.)
- Radiator Installation (Refer to GROUP 14, Radiator P.14-53.)
- Engine control module Installation (Refer to GROUP 13B, Engine Control Module P.13B-1022.)
- Battery and Battery Tray Installation (Refer to GROUP 54A, Battery P.54A-10.)
- Air Cleaner Assembly Installation (Refer to GROUP 15, Air Cleaner P.15-10.)
- Exhaust Manifold Installation (Refer to GROUP 15, Exhaust Manifold P.15-26.)
- Transmission Oil Draining (Refer to GROUP 22A, On-vehicle Service –Transmission Oil Replacement P.22A-8) < M/T.>
- Transmission Fluid Draining (Refer to GROUP 23A, On-vehicle Service –Transmission Fluid Replacement P.23A-136) <CVT.>
- Engine Oil Refilling (Refer to GROUP 12, On-vehicle Service –Engine Oil Replacement P.12-5.)
- Engine Coolant Refilling (Refer to GROUP 14, On-vehicle Service – Engine Coolant Replacement P.14-26.)
- Drive Belt Tension Check (Refer to P.11C-8.)
- Fuel Leak Check.
- Engine Room Under Cover Front and Engine Room Side Cover Installation (Refer to GROUP 51, Under Cover P.51-20.)
- Engine Upper Cover Installation (Refer to P.11C-24.)
- Hood Installation (Refer to GROUP 42A, Hood P.42A-7.)



<>

Removal steps

- 1. Control wiring harness connection
- Battery cable connection 2. Radiator upper hose connection
- <<**A**>> >>E<<

3.

- <<**A**>> >>E<<
- 4. Radiator lower hose connection
- 5. Heater hose connection
- 6. Emission vacuum hose connection

AC506785AC

Removal steps (Continued)

- 7. Brake booster vacuum hose connection
- Cooling water line hose connection 8.
- Fuel high-pressure hose >>**D**<< 9. connection



<<E>>>

<<F>>

AC609240AC

Removal steps (Continued)

CVT assembly <CVT>

12. Grounding cable connection

>>B<< 13. Engine mounting insulator

11C-83

Removal steps

< <c>></c>		10.	Power steering oil pump assembly
< <d>></d>	>>C<<	11.	A/C compressor and clutch

assembly Manual transaxle assembly <M/T>

Required	Special	Tools:
	opeoiai	

<<E>>

- MB991454: Engine Hanger Balancer
- MB991895: Engine Hanger

• MB991928: Engine Hanger

•

<<G>>> >> A<< 14. Engine assembly

• MB992201: Engine Hanger Plate

REMOVAL SERVICE POINTS

<<A>> RADIATOR UPPER HOSE/RADIATOR LOWER HOSE DISCONNECTION

Mating marks AC606081AH Make mating marks on the radiator hose and the hose clamp as shown to install them in the original position. Then, remove them.

<> FUEL HIGH-PRESSURE HOSE DISCONNECTION

1. Remove the stopper of the fuel high-pressure hose.





2. Raise the retainer of the fuel high-pressure hose and pull out the fuel high-pressure hose in the direction shown in the figure.

NOTE: If the retainer is released, install it securely after removing the fuel high-pressure hose.

<<C>> POWER STEERING OIL PUMP ASSEMBLY REMOVAL

- 1. Remove the power steering oil pump assembly together with the hose from the bracket.
- 2. Tie the removed power steering oil pump assembly with a string at a position where it will not interfere with the removal and installation of engine assembly.

TSB Revision	

<<D>> A/C COMPRESSOR AND CLUTCH ASSEMBLY REMOVAL

- 1. Remove the A/C compressor and clutch assembly together with the hose from the bracket.
- 2. Tie the removed A/C compressor and clutch assembly with a string at a position where it will not interfere with the removal and installation of engine assembly.

<<E>> MANUAL TRANSAXLE ASSEMBLY <M/T>/CVT ASSEMBLY <CVT> REMOVAL

- 1. Install the front end upper bar bolts to the position as shown in the figure.
- Remove the transaxle assembly (Refer to GROUP 22A, Transaxle Assembly P.22A-12) <M/T> or (Refer to GROUP 23A, Transaxle Assembly P.23A-152) <CVT.>



<<F>> ENGINE MOUNTING INSULATOR REMOVAL

When supporting the engine assembly with a garage jack, be careful not to deform the engine oil pan.

1. Place a garage jack against the engine oil pan with a piece of wood in between to support the engine assembly.

ENGINE MECHANICAL <2.4L ENGINE> ENGINE ASSEMBLY



- Remove special tool MB991928 or MB991895 and MB992201 which was installed for supporting the engine assembly when the transaxle assembly was removed (Refer to GROUP 22A, Transaxle Assembly P.22A-12) <M/T> or (Refer to GROUP 23A, Transaxle Assembly P.23A-152) <CVT.>
- 3. Operate a garage jack so that the engine weight is not applied to the engine mounting insulator, and remove the engine mounting insulator.



<<G>> ENGINE ASSEMBLY REMOVAL

- 1. Mount the special tool MB991454 to the power steering oil pump bracket and the engine hanger, and set the chain block.
- 2. After checking that all cables, hoses and wiring harness connectors and so on are disconnected from the engine, lift the engine assembly slowly with the chain block to remove the engine assembly upward from the engine compartment.

INSTALLATION SERVICE POINTS

>>A<< ENGINE ASSEMBLY INSTALLATION

Install the engine assembly, being careful not to pinch the cables, hoses, or wiring harness connectors.



>>B<< ENGINE MOUNTING INSULATOR INSTALLATION

When supporting the engine assembly with a garage jack, be careful not to deform the engine oil pan.

- 1. Place a garage jack against the engine oil pan with a piece of wood in between, and install the engine mounting insulator while adjusting the position of the engine assembly.
- 2. Remove special tool MB991454.

ENGINE MECHANICAL <2.4L ENGINE> ENGINE ASSEMBLY



 Install special tool MB992201 and MB991928 or MB991895 which is used during installation of transaxle assembly to hold the engine assembly (Refer to GROUP 22A, Transaxle Assembly P.22A-12) <M/T> or (Refer to GROUP 23A, Transaxle Assembly P.23A-152) <CVT.>



MB991895 AC611563AE

>>C<< A/C COMPRESSOR AND CLUTCH ASSEMBLY INSTALLATION

Tighten A/C compressor and clutch assembly mounting bolts to the specified torque in the order of number shown in the illustration.

Tightening torque: 23 \pm 6 N[.] m (17 \pm 4 ft-lb)

TSB	Revision	



>>D<< FUEL HIGH-PRESSURE HOSE CONNECTION

After connecting the fuel high-pressure hose, slightly pull it in the pull-out direction to check that it is installed firmly. In addition, check that there is approximately 3 mm (0.12 inch) play. After the check, install the stopper securely. Apply a small amount of engine oil to the fuel line pipe, and install the fuel high-pressure hose.



>>E<< RADIATOR LOWER HOSE/RADIATOR UPPER HOSE CONNECTION

- 1. Insert radiator hose as far as the projection of the water inlet fitting or water outlet fitting.
- 2. Align the mating marks on the radiator hose and hose clamp, and then connect the radiator hose.



NOTES